


WALL MOUNT SHELF

Assembly Instructions



Thank you for your purchase!

Iron Age Office furniture is uniquely and individually fabricated. For this reason, your furniture is pre-assembled and labeled before shipping. Labels are marked on the underside of the furniture. The furniture is then deconstructed prior to shipping. Pieces that uniquely correspond can typically be found on the same pallet.

Assembly is best completed by keeping the pieces that correspond together. Clear your work area of anything that could scratch furniture surfaces. If possible, cover your work area with a clean, soft blanket. Carefully flip any wooden tops over and inspect the bottom sides for markings. Match legs, flat brackets, etc. to the appropriate labels.

If you need further assistance of any kind,
please contact:

Iron Age Office Operations Manager

Henry Dover


678-725-1473 (c)

hd@ironageoffice.com

ASSEMBLY


STEP 1

Identify the stud locations on the wall you would like to hang the shelf on.




STEP 2

Predrill 6 holes into wall shelf according to the spacing of your wall studs.



STEP 3


Align wall shelf to desired location on wall and secure with screws through the predrilled holes into the wall studs.



ASSEMBLY

STEP 4

Enjoy your shelf!



CARE INSTRUCTIONS

To care for either wooden or metal surfaces of Iron Age Office products, gently wipe with a soft cloth dampened with water and a mild dishwashing liquid. Once satisfied, dry with a soft cloth.